



rammount.com
1-800-497-7479
sales@rammount.com

RAM® Round Plate with Ball - C Size

Part # RAM-202U **UPC** 793442001239 **Ball Size** C
Price \$19.49



OVERVIEW

The RAM® Round Plate with Ball (RAM-202U) features a 1.5" C size overmolded rubber ball attached to a 2.5" diameter round plate. This mounting component includes pre-drilled holes in the universal 4-hole AMPS pattern and is constructed from powder-coated, marine-grade aluminum for long-lasting durability in demanding environments. The ball base can function as an adapter—connecting to devices or holders with matching hole patterns—or as a drill-down base mounted directly to a surface.

FEATURES

- 2.5" round plate connects to RAM® device holders containing the universal AMPS hole pattern
- Included C size 1.5" RAM® rubber ball allows for connection to any C size RAM® double socket arm; ball and socket technology allows for near-infinite adjustability
- Made of powder-coated, marine-grade aluminum for durability and reliability in the most demanding environments
- Backed by a lifetime warranty

SPECIFICATIONS

Hole Pattern	4-Hole AMPS: 1.181" x 1.496" 3-Hole 120-Degree: 1.812" Diameter
Plate Size	2.5" Diameter
Ball Size	C Size (1.5")
Weight Capacity	Standard Use: 4 lbs Heavy-Duty Use: 3 lbs

Materials	Marine-grade aluminum
Packaging Type	Poly Bag
Weight	0.23 lb