



rammount.com
1-800-497-7479
sales@rammount.com

RAM® Double Socket Arm - C Size Medium

Part # RAM-201U **UPC** 793442001215 **Ball Size** C
Arm Length Medium **Price** \$31.49



OVERVIEW

The RAM® Double Socket Arm - C Size Medium (RAM-201U) serves as the “socket” in the RAM® patented ball-and-socket mounting system. This double socket arm connects to any two C size ball adapters or bases. A spring inside the arm keeps one socket open, making it easy to attach to a ball. With an overall length of 5.69", the arm features an easy-to-adjust knob that provides near-infinite positioning.

FEATURES

- Medium length double socket arm has an overall length of 5.69" and a socket-to-socket length of 4.66"
- Attaches to any C size RAM® ball component, including mounting bases and device holders; double ball and socket technology allows for near-infinite adjustability of your RAM® mounting system
- Made of powder-coated, marine-grade aluminum for durability and reliability in the most demanding environments
- Backed by a lifetime warranty

SPECIFICATIONS

Product Dimensions	Overall Length: 5.69"
Socket To Socket Length	4.66"
Ball Size	C Size (1.5")
Weight Capacity	Standard Use: 4 lbs Heavy-Duty Use: 3 lbs
Materials	Marine-grade aluminum

Packaging Type	Poly Bag
Warranty	Lifetime
Weight	0.75 lb

KIT COMPONENTS

- **RAM-2-1U** RAM® Knob, Bolt & Spring Hardware for C Size Socket Arms

rammount.com/products/ram-201u