



rammount.com
1-800-497-7479
sales@rammount.com

RAM® Double Socket Arm - B Size Medium

Part # RAM-B-201U **UPC** 793442002106 **Ball Size** B
Arm Length Medium **Price** \$20.49



OVERVIEW

The RAM® Double Socket Arm (RAM-B-201U) is a rugged medium-length double socket arm compatible with B size rubber ball adapters and bases. A single spring inside the arm pushes one end open as the arm is loosened, allowing for easy rotation of the ball and socket connection at both ends. This ball-and-socket technology allows for near-infinite adjustment and perfect viewing angles when used with RAM® rubber ball bases.

FEATURES

- Standard RAM® double socket arm provides an ideal overall length of 3.73" and a socket-to-socket length of 3"
- Attaches to any B size RAM® ball component, including mounting bases and device holders; double ball and socket technology allows for near-infinite adjustability of your RAM® mounting system
- Made of powder-coated, marine-grade aluminum for durability and reliability in the most demanding environments
- Backed by a lifetime warranty

SPECIFICATIONS

Product Dimensions	Overall Length: 3.73"
Socket To Socket Length	3"
Ball Size	B Size (1")
Weight Capacity	Standard Use: 2 lbs Heavy-Duty Use: 1 lb
Materials	Marine-grade aluminum

Packaging Type	Poly Bag
Weight	0.32 lb

KIT COMPONENTS

- **RAM-B-201U-WD1** RAM® Double Socket Arm Halves without Bolt, Knob or Spring
- **RAM-B-2-1** RAM® T-Knob with Bolt, Washers & Spring for Socket Arms

rammount.com/products/ram-b-201u